

Schemat podłączenia do instalacji samochodu



STAG 400.4 DPI

E8 67R - 01 5753
110R - 00 5754







"04-105.95.00.2 z dn. 07.09.2016"



AC S.A.
15-181 Białystok, ul. 42 Pułku Piechoty 50
tel. +48 85 743 81 00, fax +48 85 653 93 83
www.ac.com.pl | info@ac.com.pl



PC



Wiring Diagram

STAG 400.4 DPI

E8 67R - 01 5753
110R - 00 5754

"04-105.95.00.2 z dn. 07.09.2016"




Схема подключения к автомобильной установке


STAG 400.4 DPI

Ⓔ 8 67R - 01 5753
110R - 00 5754

"04-105.95.00.2 z dn. 07.09.2016"



AC S.A.
15-181 Białystok, ul. 42 Pułku Piechoty 50
tel. +48 85 743 81 00, fax +48 85 653 93 83
www.ac.com.pl | info@ac.com.pl



Esquema de conexión a la instalación del vehículo.

STAG 400.4 DPI

E8 67R - 01 5753
110R - 00 5754

"04-105.95.00.2 z dn. 07.09.2016"



AC S.A.
15-181 Białystok, ul. 42 Pułku Piechoty 50
tel. +48 85 743 81 00, fax +48 85 653 93 83
www.ac.com.pl | info@ac.com.pl




Diagrama de fiação

STAG 400.4 DPI

E8 67R - 01 5753
110R - 00 5754

"04-105.95.00.2 z dn. 07.09.2016"



AC S.A.
15-181 Białystok, ul. 42 Pułku Piechoty 50
tel. +48 85 743 81 00, fax +48 85 653 93 83
www.ac.com.pl | info@ac.com.pl




Schéma pour le raccordement à la voiture

STAG 400.4 DPI

E8 67R - 01 5753
110R - 00 5754

"04-105.95.00.2 z dn. 07.09.2016"



AC S.A.
15-181 Białystok, ul. 42 Pułku Piechoty 50
tel. +48 85 743 81 00, fax +48 85 653 93 83
www.ac.com.pl | info@ac.com.pl

